

SERVICE MANUAL

Lil Ticket Monsters



PLACE SERIAL NUMBER LABEL HERE

FACTORY CONTACT INFORMATION



BAY TEK ENTERTAINMENT
Pulaski Industrial Park
1077 East Glenbrook Drive
Pulaski, WI 54162 USA

SIGN UP TO RECEIVE OUR E-MAILS!

Stay up to date on the latest game information, new product launches, early notification of parts specials, updates of retro fit parts, software upgrades, best practices and more!

Visit baytekent.com and enter your email to sign up!

You can also register your new game at baytekent.com/register

SALES

Phone: (920) 822-3951 Ext. 2
Fax: (920) 822-8936
Email: baytek.sales@thevillage.bz

PARTS

Phone: (920) 822-3951 Ext. 1101
Email: baytek.parts@thevillage.bz

SERVICE

Phone: (920) 822-3951 Ext. 1102
Email: baytek.service@thevillage.bz

**Open Monday - Friday
8 AM - 5 PM C.S.T.**

All games are proudly manufactured at our factory in Pulaski, Wisconsin, USA

TABLE OF CONTENTS

FACTORY CONTACT INFORMATION	2
TABLE OF CONTENTS	3
WELCOME TO LIL' TICKET MONSTER	4
GAME SPECIFICATIONS	5
SAFETY PRECAUTIONS	6
REMOVABLE MARQUEE	6
GAME SET UP	7 - 12
CARD SWIPE INSTALLATION	13
AVAILABLE BLANKING PLATES	13
GAME PLAY THEORY OF OPERATION	14
MAIN MENU FUNCTIONS	15
AUDIO SETTINGS	16
PAYOUT SETTINGS MENU	17
TICKET PATTERNS	18 - 19
GAME SETTINGS MENU	20
STATISTICS MENU	20
DIAGNOSTIC MENU	21
HOW TO LOCATE CIRCUIT BOARDS	22
DIPSWITCH SETTINGS	22
CIRCUIT BOARD LAYOUT	23
WIRING DIAGRAMS	24 - 28
TROUBLESHOOTING GUIDE	29 - 34
BILL ACCEPTOR DIAGNOSTICS	34
POWER SUPPLY DIAGNOSTICS	35
HOW TO CHANGE SOFTWARE	36
I/O AUX BOARD PINOUT	36
HOW TO OPEN THE FRONT PLEXI	37
HOW TO REMOVE ARROW SENSOR	37
HOW TO ADJUST ARROW SENSOR	38
HOW TO ADJUST BRAKE TENSION	38
HOW TO REMOVE HOME SENSOR	39
HOW TO REPLACE MONITOR	39
HOW TO REPLACE SOLENOID	40 - 42
HANDLE ASSY EXPLODED VIEW	43
DECAL DIAGRAM	44
PARTS LIST	45 - 46
PARTS PICTURES	47 - 49
MAINTENANCE LOG	50
TECHNICAL SUPPORT	51
WARRANTY	52

WELCOME TO LIL TICKET MONSTER

Congratulations on your purchase!

The beloved Lil' Monsters : Burb, Grunt, and Toot are delighted to be a part your game room! The Lil' Monsters are fun and friendly to all age groups, creating multi-generation appeal to anyone that steps through your doors!

Please take a moment to read through this manual and be sure to contact our factory if you have any questions, or would like some more information.

Thank you for your purchase!

Your business is important to us and we hope you enjoy this product as much as we do!

Your Friends at Bay Tek Entertainment



GAME SPECIFICATIONS

WEIGHT

GAME WEIGHT	386 lbs.	175 kg
SHIP WEIGHT	471 lbs.	214 kg

GAME DIMENSIONS

WIDTH	30.75"	79 cm
DEPTH	43"	110 cm
HEIGHT	106.25"	270 cm

OPERATING TEMPERATURE

FAHRENHEIT	45 - 80 F
CELSIUS	7.2 - 26.7 C

SHIPPING DIMENSIONS

PALLET	60"x 40"x 92"	471 lbs. class 125
--------	---------------	--------------------

POWER REQUIREMENTS

INPUT VOLTAGE	100-120 VAC	220-240 VAC
INPUT FREQUENCY	60 Hz	50/60 Hz

MAX OPERATING CURRENT

2.8 AMPS @ 115 VAC

1.4 AMPS @ 230 VAC

Note: The marquee artwork can be removed to lower game to 7' 6" (90 Inches)



106.25"
270 cm

91"
231 cm

GAME INSPECTION

Please inspect the game for any damaged, loose, or missing parts.


If damage is found, please contact your freight carrier first.
Then, contact Bay Tek Entertainment's Service Department at
(920) 822-3951 Ext. 1102

Or email us at baytek.service@thevillage.bz for further assistance.

SAFETY PRECAUTIONS

NOTICE
Modifications to the mechanical, electrical and structural components of this game may void its compliance certifications.
This appliance is suitable for INDOOR, DRY locations only.
DANGER
DO NOT perform repairs or maintenance on this game with the power ON. Unplug the unit from the wall outlet or shut off the power strip located inside the cabinet.
WARNING
Use of flammable substances can cause sever burns or serious injury. Always use NON-FLAMMABLE solvents for cleaning. DO NOT use gasoline kerosene or thinners.
CAUTION
Lifting heavy objects can cause back, neck or other injuries. Be sure adequate lifting and moving devices are available when unloading, unpacking and moving this game.
ATTENTION
Be sure the electrical power matches the game requirements. See the serial number located on the back of the game cabinet. Always plug into a grounded circuit. If the supply cord is damaged, it must be replaced by an approved cord or assembly provided by the manufacturer. A shielded power cable must be used for the game to retain EU/EMC compliance.
IN CASE OF EMERGENCY
UNPLUG THE POWER CORD. The power cord must be accessible at all times in case of an emergency.

REMOVABLE MARQUEE



LIL TICKET MONSTER GAME SETUP

The game will arrive on one pallet.
Please inspect the pallet for shipping damage and report immediately to the freight company if any damage is found.



Remove the cardboard from the pallet.

Carefully remove the plastic wrap securing the printed plexi wrapped to the side of the cabinet. Save this printed plexi for later installation.

Remove the large plastic bag from the cabinet and proceed to assembly instructions.

Tools Needed:

1 step ladder (4-6 foot) #2 square bit screwdriver
9/16" wrench Phillips screwdriver 11/32" wrench

Remove the protection plastic from the front plexi.

Remove the keys from the small plastic bag taped to the top console.

Unlock the front door using a H95 key.



Important!

Remove the **first of 2 shipping bolts** using a 9/16" wrench.

There is another shipping bolt accessed from the back door.

Unlock the coin box door using a A05/E00 key.



Remove the hardware kit (Part # A5KIT-LTM), wood blocks and service manual from the coin box.

Remove the eyeball light to be installed later.

Close and lock coin box door, remove key to allow the front door to close fully.



LIL TICKET MONSTER GAME SETUP

Hardware kits consist of:

32 of A5SCPH151 used to install the eyeball light and printed plexi wrap.
 2 of A5SCPH230 and 2 of A5NULO030 used to secure plexi wrap below monitor.

1 of A5BOHH060, 1 of A5WASI020, and 1 of A5WAFL060 are to be saved with the wood blocks and used to support the wheel in case of a future solenoid replacement.



A5SCPH151



A5NULO030




A5SCPH230



A5BOHH060



A5WASI020



A5WAFL060

Unlock the back door using a H95 key.

Remove the back door by using both handles to lift upwards and pull out.




Important!

Remove the 2nd of 2 shipping bolts using a 9/16" wrench.

Ensure the shipping bolt from the front door is also removed.

Replace the back door and remove the game from the pallet.




Using a ladder, carefully position the eyeball light on top of the game by positioning it inline with pilot holes.

Secure using 2 of the black screws from the hardware kit using a #2 square bit screwdriver.



A5SCPH151

Connect the CE22506 cable from eyeball light to the game cable CE22505 located in the top of the game.



LIL TICKET MONSTER GAME SETUP

Rotate upper marquee in place:

Remove the lower bolt (A5BOPH320) from both left and right sides of marquee arm.
Leave the top bolt in place.



Rotate the marquee upward and re-insert the same bolts previously removed into the left hole.

Do this on both arms of the marquee.



Install the printed plexi wrap.

Remove the clear protective film from both sides of the printed plexi wrap.

The idea is to secure **one** screw into the left side of the plexi, then wrap it around the game and install screws into the right side.

The first screw to be installed will be this one. Line up the printed plexi with this pilot hole and insert 1 of the black screws from the hardware kit using a #2 square bit screwdriver.



A5SCPH151



LIL TICKET MONSTER GAME SETUP

Pull the printed plexi wrap around the front of the game tightly, with the eyeball light through the round cutout in the plexi.

Continue wrapping the top of the cabinet and get ready to insert one screw in this location.

Line up the printed plexi with this pilot hole and insert 1 of the black screws from the hardware kit using a #2 square bit screwdriver.



A5SCPH151


Make sure the bolt hole is centered in the hole of the printed plexi.

Pull the printed plexi snugly until this bolt is centered in the hole of the printed plexi.

Insert another of the black screws from the hardware kit using a #2 square bit screwdriver.



A5SCPH151



LIL TICKET MONSTER GAME SETUP

Continue installing the black screws from the hardware kit using a #2 square bit screwdriver in both the left side and right side printed plexi wrap.



A5SCPH151

There are a total of 15 screws in each side.

If the plexi bulges in spots, it may be necessary to remove screws close to bulge and re-install screws.



LIL TICKET MONSTER GAME SETUP

Install the 2 center bolts and nuts under the monitor.

The printed plexi wrap is secured to small “L” brackets using a Phillips bolt and nut from the hardware kit.



A5NULO030




A5SCPH230



Push the 2 bolts through the printed plexi, through the hole in the “L” bracket, and secure with the nut by reaching under the lip of the plexi.

Secure using a Phillips screwdriver and 11/32” wrench.



Remove the power cord from the coin box, and thread the power cord through this hole, out the rear of the cabinet and plug into a grounded outlet.



Power on game:

Open the front door and turn on the rocker switch on the power strip along the right side of coin box.

The rocker switch is located behind the 1st power cord on the strip



The game is now set up and ready for play!

Enter menu to adjust settings to your location specific price per play and ticket payout.

CARD SWIPE SYSTEM INSTALLATION


The Lil Ticket Monster game is pre-wired with an UCL (Universal Card Link) connector to accept Card Swipe systems from many different manufacture's. Please follow these instructions to make full use of this capability.

Option #1:

Card swipe systems may come with a standard 9 pin Molex connector. This is the UCL connector. Simply plug this connector into your card swipe reader.

Note:


- Many card swipe systems have a voltage threshold that can be adjusted in the card swipe menu. Please set this "Game Drive Threshold" to 2 Volts.



Option #2:

If your card swipe systems does not have a standard 9 pin Molex connector, then you will have to splice wires into the AACE26013 harness.

Black wire is ground. (common)
Green wire is coin signal.
Yellow wire is +12 Volts DC



Menu Changes

- Enter menu, go to "Payout" Menu
- Verify "Credits" set to 1
- Verify "Card Reader" set to "Enabled"

Check dipswitches on the I/O Aux Board in the front of game. Verify Dipswitch # 5 ON

AVAILABLE BLANKING PLATES



A5PL4200 DBA Plate for 12V Upstacker Bill Acceptor



A5PL9998 Plate used instead of Coin Mechanisms



A5PL8900 Plate used for Bill Validator



A5PL9995 Plate used instead of ticket dispenser

GAME PLAY THEORY OF OPERATION

The game is designed to give tickets after the player lifts, then pushes down on the plunger handle.

Upon coin up, the solenoid on the left side of the wheel will engage and provide a mechanical link from the plunger handle to the wheel.

As the plunger is pushed down, the wheel will start spinning.

The solenoid will stay engaged, allowing the player to plunge again to spin faster until a “Good Spin” wheel speed is achieved.

Once the wheel is spinning at or above this “Good Spin” wheel speed, the solenoid will disengage.

The “Good Spin” wheel speed is measured by the Wheel Encoder Sensor located in the arrow in the right front of the wheel.

This Wheel Encoder Sensor also detects the notched edge around the right edge of the wheel to determine how far away it is from the “Home Position”.

The “Home Position” is kept track of by the Home Sensor located on the right side of the wheel.

The Home Sensor (accessed from the back of the game) sees a reflection from a metal tab mounted on the wheel, seeing the reflection once per rotation.

This calculation of the Wheel Encoder Sensor and the Home Position Sensor allows the game to determine which position the wheel lands on and provides that amount of tickets to the player.



MAIN MENU FUNCTIONS

The Menu and Menu Select buttons are located inside the front door.


Hold the MENU button down for 1 second to open the main menu on the monitor.

Press MENU to scroll through the options, and MENU SELECT to change the settings.



MAIN MENU		
Clear Credits and Tickets	Press the MENU SELECT button 5 times to clear credits and tickets owed	
Mute	ON (No sound from game)	OFF
Attract and Volume	Press MENU SELECT to enter the Attract and Volume Settings Menu	
Payout	Press MENU SELECT to enter the Payout Settings Menu	
Game Settings	Press MENU SELECT to enter the Game Settings Menu	
Statistics	Press MENU SELECT to enter the Statistics Menu	
Diagnostics	Press MENU SELECT to enter the Diagnostic Menu	
Exit	Press MENU SELECT button to exit menu	

*** Default settings are highlighted in yellow



Software versions are shown on the bottom left corner of the main menu screen.

Software Version: 1.0
Doorboard Version: 1.7
Wheelboard Version: 1.0
Lightboard Version: 1.0

If "Not Found" is displayed, then the circuit board is not communicating to motherboard.

Door Board Version: Not Found

ATTRACT AND VOLUME MENU

Scroll through the options by pressing the “MENU” button.

Change selection with the “SELECT” button.

Scroll to “BACK” and press the “SELECT” button to go back to the main menu.

Default settings are highlighted in yellow below.

ATTRACT AND VOLUME

Attract Time (mins): 3

Attract Volume: 4

Game Volume: 6

Bonus Volume: 8

Back>

ATTRACT TIME

DISABLED	1	2	3	4	5	6	7	8	9	10
----------	---	---	---	---	---	---	---	---	---	----

Sets the amount of minutes between the attract mode cycles.

“DISABLED” means that there will be no attract sounds.

ATTRACT VOLUME

OFF	1	2	3	4	5	6	7	8	9	10
-----	---	---	---	---	---	---	---	---	---	----

Sets the attract volume on a sliding scale. OFF means no attract volume.

GAME VOLUME

OFF	1	2	3	4	5	6	7	8	9	10
-----	---	---	---	---	---	---	---	---	---	----

Sets the game volume on a sliding scale. OFF means no game play volume.

BONUS VOLUME


OFF	1	2	3	4	5	6	7	8	9	10
-----	---	---	---	---	---	---	---	---	---	----

Sets the bonus celebration volume on a sliding scale. OFF means no bonus celebration volume.

PAYOUT SETTINGS MENU

Scroll through the options by pressing the “MENU” button.
 Change selection with the “SELECT” button.
 Scroll to “BACK” and press the “SELECT” button to go back to the main menu.

Default settings are highlighted in yellow below.



CREDITS

FREE	1	2	3	4	5	...	17	18	19	20
------	---	---	---	---	---	-----	----	----	----	----

Sets the amount of credit pulses needed to start a game.
 “Free Game” means the game will always be in play mode.

CARD SWIPE

SWIPE CARD	TAP CARD	INSERT CREDITS
------------	----------	----------------

Shows the verbiage on the screen to match your locations setup.

REDEMPTION TYPE

COUPONS	TICKETS	POINTS
---------	---------	--------

Sets the wording that will show on the screen for the player.

TICKET PATTERN

FIXED TICKETS	1	2	3	4
---------------	---	---	---	---

Sets the ticket pattern for game play. Available patterns are described on the next page.
 Default is \$1.00 per game.

FIXED TICKETS

Disabled	1	2	3	4	5	...	24	25
----------	---	---	---	---	---	-----	----	----

Sets the amount of tickets that will be given if the player **only** if “Ticket Pattern” is set to Fixed Tickets

MINOR BONUS VALUES

15	50	100	250
----	----	-----	-----

Sets the amount of tickets for the 3 minor bonus locations on the wheel.

MAJOR BONUS VALUE

50	100	250	500	1000	2000
----	-----	-----	-----	------	------

Sets the amount of tickets for the 1 major bonus location on the wheel.

TICKET PATTERNS

There are 4 base ticket patterns to choose from. These base patterns can be adjusted by adding cover-up decals to the wheel over the minor and major bonus values. Base ticket values and minor and major bonus values can be changed in the "Payout Settings Menu" Tickets per game shown are average payout over time.

PATTERN 1 (low)	PATTERN 2 (medium)	DEFAULT PATTERN 3 (large)	PATTERN 4 (XL)	
10	20	50	75	
3	5	15	20	
5	10	20	30	
50	50	100	250	
10	20	50	75	
3	5	15	20	
5	10	20	30	
50	50	100	250	
10	20	50	75	
3	5	15	20	
5	10	20	30	
50	50	100	250	
10	20	50	75	
3	5	15	20	
5	10	20	30	
100	500	1000	1000	
10	20	50	75	
3	5	15	20	

Avg. Tix 5-15


Avg. Tix 10-20

Avg. Tix 20-45

Avg. Tix 40-60

TICKET PATTERNS

There are 4 base ticket patterns to choose from. These base patterns can be adjusted by adding cover-up decals to the wheel over the minor and major bonus values. Base ticket values and minor and major bonus values can be changed in the "Payout Settings Menu" Tickets per game shown are average payout over time.



How to change ticket payout:


The tickets per game can be modified by purchasing a set of cover up decals and placing them over the existing number on the wheel. Order part # AADE22510




GAME SETTINGS MENU

Scroll through the options by pressing the “MENU” button.
Change selection with the “SELECT” button.
Scroll to “BACK” and press the “SELECT” button to go back to the main menu.

Default settings are highlighted in yellow below.



ENTERTAINMENT ONLY



“ON” will not dispense tickets.

TIMEOUT

Disabled	30	60	90	120	...	300
----------	----	----	----	-----	-----	-----

Sets the amount of seconds that the game will wait for the player to spin the wheel.
After this amount of time, the game will award 4 tickets and go to “Game Over”
“Disabled” means no timeout.

STATISTICS MENU

Scroll through the options by pressing the “MENU” button.

The Statistics Menu displays the:


- Total Games Played
- Total Game Time
- Average Game Time
- Number of Game Timeouts
- Total Tickets Dispensed
- Average Tickets Dispensed Per Game
- Total Bonus Tickets Dispensed



Clear Statistics - Press the “SELECT” button 5 times to Reset Statistics.

Scroll to “BACK” and press the “SELECT” button to go back to the main menu.

DIAGNOSTIC MENU



Ticket value on the wheel where arrow is pointing.
Important: The wheel must be spun downward for this to be correct.

Explained on the bottom of this page.

Graphic representation of wheel speed as it's turning.

Revolutions Per Minute of wheel as it's turning.

Brake Status: Give the wheel a fast spin and allow it to coast to a stop. This will show "Brake OK" when brake is set correctly.

Stop time: Amount of time the wheel coasts to a stop

ENGAGE WHEEL

Press the "Menu Select" button to engage the solenoid. This will allow the wheel to turn by pushing the plunger down.

DISENGAGE WHEEL

Press the "Menu Select" button to un-power the solenoid.

ADD CREDIT

Will send one credit pulse to game when the "Add Credit" option is selected.

TEST TICKET DISPENSER

Will send one ticket enable pulse to dispenser when the "Dispense Tickets" option is selected.

RESET TO DEFAULTS

All Menu Options will change to the Factory Default settings when selected.

Doorboard 1
 Credits: 0
 Tickets: 148
 Show Mode: Off
 Low Tickets: Yes


"Doorboard 1" sections will show:
 Total amount of credits in memory
 Total amount of tickets owed.
 Status of the "Show Mode" dipswitch on the I/O board.
 Status of the low ticket switch.

Wheelboard
 Current Position: 7
 Current Ticket Value: 3
 Notch Sensor:
 Home Sensor:
 Wheel Engaged:

"Wheelboard" sections will show:
 Current position of wheel (From 0-32)
 Current Ticket Value - The ticket value that arrow is pointing at.
 "Notch Sensor" will light as the encoder sensor sees a notch as the wheel is turning.
 "Home Sensor" will light as the home sensor sees the metal bracket on side of wheel
 "Wheel Engaged" will light when the game thinks it is sending power to the solenoid.


HOW TO LOCATE CIRCUIT BOARDS

All circuit boards can be accessed from the back door of the game.



DIPSWITCH SETTINGS







SWITCH	DESCRIPTION	ON	OFF
1	SHOW GAME Does not dispense tickets and clears all accumulated credits		X
2	AMUSEMENT ONLY Does not dispense tickets		X
3	NJ LOCKOUT Saves tickets owed and unused credits after a power loss		X
4	1/2 TICKET PAYOUT Dispenses 1/2 the amount of tickets as shown on screen. It will round up odd amounts of tickets		X
5	DISABLES LOW TICKET INPUT Disables the low ticket message on screen. This option should be enabled when using a card swipe system		X
6	NOT USED		
7	NOT USED		
8	NOT USED		




Note:
UP is ON

CIRCUIT BOARD LAYOUT


Note: All boards are located in the back of the game.




WHEEL CONTROL BOARD WIRING DIAGRAM




LIGHTING WIRING DIAGRAM



SPEAKERS AND MOTHERBOARD COMMUNICATION



AC IN & DC VOLTAGE WIRING DIAGRAM




TROUBLESHOOTING GUIDE

Troubleshooting Strategy

Use common sense and a systematic method of troubleshooting to determine the exact problem, probable cause and remedy. Use the process of elimination to find the faulty component. Always check for the simple and obvious causes first such as unplugged, loose or broken wires and bad sensors, bent, pinched, stuck or jammed components.



Troubleshooting Chart

Problem	Probable Cause	Remedy
No power to the game No lights on at all	Unplugged. Circuit breaker tripped. Line Filter Faulty. Power strip faulty. Faulty cable/power supply	Check wall outlet. Reset power strip breaker switch or building circuit breaker. Replace Line Filter (Part # A5FI9010) Swap positions, ensure rocker switch on power supply is ON, replace if needed A5OU5000 Refer to wiring diagram. Check cables CE22500 & CB15001 board. Refer to Power Supply diagnostic section
Monitor on, but everything else off (Power Supply not ON)	Power supply unplugged. Rocker Switch. Power supply shutting down because of 12 V overload. Faulty power supply. Faulty Power Dist Board	Ensure unit is plugged into power strip. Make sure rocker switch on power supply is set ON.  Refer to power supply diagnostics to isolate bad component. A bad solenoid or 12 volt short would cause this. Refer to Power Supply Diagnostic section. Replace Power Distribution Board (AACB5156)
Dollar Bill Acceptor not functioning Ensure Bill Acceptor is set to "Always Enable" Important : Only 12 Volt DBA is to be installed. Model # AE 2454 U5E Part # A5AC9101	Check for power to Bill Acceptor. Dirt or debris in acceptor slot. Pinched, broken, or disconnected wiring. Bill acceptor problem. Part # A5AC9101	Acceptor should cycle stacker at game power up. If not, check cable connections. Refer to "How to Clean Bill Acceptor" Or clean with bill reader cleaning card. (A5CC9000) Check wiring from bill acceptor to NewGen Board. (CE26008) Repair or replace wiring harness. Check connector on I/O Aux Board Make sure wires are secure in connectors. Refer to troubleshooting section of dollar bill acceptor manual included with this game or the diagnostics label of the back of the unit.
Meters do not work Game meter will click at the start of the game. Ticket meter will click as tickets come out of game and notch is "seen" by dispenser.	Ensure correct number of tickets are being dispensed Disconnected, loose or broken wires. Faulty counter.	Check ticket values in menu. Test Ticket Dispense in Diagnostic menu. Refer to Tickets not dispensing troubleshooting section. Check connections to I/O board. Cables # CE26012 and AACO1020 Replace counter. AACO1020.






TROUBLESHOOTING GUIDE

Problem	Probable Cause	Remedy
<p>Colored player console lighting not working</p> <p>LED's power the console edge first, then the plunger accent lights</p>	<p>If all colored cabinet lights are not functioning, check Light Board (AACB8001-LTM)</p> <p>If LED strip is out, check cable. Refer to "LED Light Board Wiring Diagram"</p> <p>Faulty LED</p> <p>Faulty Light Board</p>	<p>Check power to Light Board from Power Distribution Board. Cable # CE26017. Check USB cable to Light Board from motherboard. Cable # A5CORD58</p> <p>Check for proper connection from Light board to LED strips. Check continuity. Refer to "Sensor & LED Wiring Diagram" (CE26010, CE26033, CE26032)</p> <p>Replace LED (CE26033, CE26032)</p> <p>Replace Light Board. (AACB8001-LTM)</p>
<p>White lights on side of wheel not working (12 Volt LED's)</p>	<p>Faulty Cable</p> <p>Faulty LED</p>	<p>Side wheel white lights are 12 Volts DC, direct from Power Distribution Board to LED strips. Check continuity. (CE26004, CE26029) Refer to "Lighting Wiring Diagram"</p> <p>Replace LED strip CE26029</p>
<p>Colored lights on side of wheel not working (12 Volt LED's)</p>	<p>Faulty Cable</p> <p>Faulty LED</p>	<p>Side wheel colored lights are 12 Volts DC, from Light Board which communicates to motherboard via USB cable. Check continuity. (CE22501, CE26030) Refer to "Lighting Wiring Diagram"</p> <p>Replace LED strip CE26030</p>
<p>White lights in marquee do not work (12 Volt LED's)</p>	<p>Faulty Cable</p> <p>Faulty LED</p>	<p>Check for proper connection from Power Distribution Board to LED strips. Check continuity. (CE22504, CE22502) Refer to "Lighting Wiring Diagram"</p> <p>Replace LED strip CE22502</p>
<p>Colored lights in Marquee do not work (12 Volt LED's)</p>	<p>Faulty Cable</p> <p>Faulty LED</p>	<p>Check for proper connection from Light Board to LED strips. Check continuity. (CE22505, CE22503) Refer to "Lighting Wiring Diagram"</p> <p>Replace LED strip CE22503</p>
<p>Eyeball Light in top of game does not work (12 Volt LED's)</p>	<p>Faulty Cable</p> <p>Faulty LED</p>	<p>Check for proper connection from Light Board to LED strips. Check continuity. (CE22505, CE22506) Refer to "Lighting Wiring Diagram"</p> <p>Replace round LED board CE22506</p>
<p>No Sound</p> <p>Motherboard creates sound, Audio board amplifies it.</p>	<p>Volume set to zero in menu. Ensure "Mute" is set to OFF</p> <p>Disconnected, loose or broken wires.</p> <p>Faulty speaker.</p>	<p>Enter Attract & Volume Menu and verify: Game Volume & Attract Volume are not zero</p> <p>Check connections and reseat audio cable from motherboard to Audio Amplifier board to speakers. Cables # A5CORD21 from green socket on motherboard, A5CE2300, CE26001</p> <p>Ensure 12 volts at CE26018 cable from power supply.</p> <p>Unplug audio jack cable (A5CORD21) from motherboard, plug into MP3 player and see if music is amplified and comes out of speaker.</p> <p style="padding-left: 20px;">If Yes - then motherboard is faulty.</p> <p style="padding-left: 20px;">If No - then Audio Amplifier Board (AACB9600A) may be faulty.</p> <p>Replace speaker. AACE8811</p>

TROUBLESHOOTING GUIDE

Problem	Probable Cause	Remedy
<p>Tickets do not dispense or Wrong amount dispensed.</p> <p>Check for the correct amount of tickets showing on Monitor</p>	<p>Tickets on monitor does not match tickets coming out of game.</p>	<p>Opto Sensor on ticket dispenser dirty.</p> <p>Faulty ticket dispenser.</p> <p>Notch on tickets cut too shallow.</p> <p>Faulty cable. Disconnected, loose or broken wires.</p> <p>Enter Diagnostic menu and test Dispenser</p> <p>Check dipswitches on I/O Aux Board</p> <p>Faulty I/O Aux Board</p>
	<p>Tickets on monitor do match tickets coming out of game.</p>	<p>Settings in Menu are incorrect.</p> <p>Home Sensor not working properly.</p> <p>Encoder Sensors not working properly.</p>
<p>Low Tickets message on monitor</p>	<p>Tickets are empty in ticket tray</p> <p>Faulty cable. Disconnected, loose or broken wires.</p> <p>Faulty low ticket switch.</p> <p>Faulty I/O Aux Board</p>	<p>Load tickets into tray. Ensure tickets hold down micro switch wire.</p> <p>Check connectors from low ticket switch to I/O Aux board. Check for continuity. (CE26013)</p> <p>Inspect switch and replace if needed. (AASW200)</p> <p>Check dipswitches on I/O Board, Replace I/O Aux Board if needed. AACB9605A-CBL</p>
<p>Light Board Issue</p> <p>Colorful lights around console and window are not flashing.</p> <div style="display: flex; align-items: center; margin-top: 10px;"> <div style="margin-right: 10px;"> <p>Red and Yellow LEDs</p>  </div>  </div>	<p>Red power LED is normally on.</p> <p>Yellow and red LED are normally on.</p> <p>Faulty Light Board.</p>	<p>If it is off, then check 12 & 5 Volts DC coming into board on cable CE26017 from Power Distribution Board.</p> <p>If solid on, then it is not communicating with the motherboard. Check A5CBL5900 USB cable. Swap cable with Wheel Control Board.</p> <p>Watch during attract mode and see if it flashes for a short time. Check A5CBL5900 USB cable. Swap cable with the Wheel Board.</p> <p>Replace Light Board if needed. Part # AACB8001-LTM</p>

TROUBLESHOOTING GUIDE

Problem	Probable Cause	Remedy
<p>I/O Aux Board Issue Game does not coin up, and has no other functions.</p> 	<p>Green power LED should be flashing.</p> <p>Red and Yellow LED's should be ON.</p> <p>Faulty I/O Aux Board</p>	<p>If it is off, then check 12 & 5 Volts DC coming into board on cable CE26014 from Power Distribution Board.</p> <p>If solid on, then it is not communicating with the motherboard. Check A5CBL5900 USB cable. Swap cable with the light board.</p> <p>If they are off, it is not communicating with the motherboard. Check A5CBL5900 USB cable. Swap cable with the light board</p> <p>Replace I/O Aux Board if needed. Part # AACB9605A-MCC</p>
<p>Wheel Board Issue Solenoid will not engage, and sensor will not see wheel.</p> 	<p>Red power LED should be on.</p> <p>Yellow LED is normally off, and only flashes when communicating.</p> <p>Faulty Wheel Board</p>	<p>If it is off, then check 12 & 5 Volts DC coming into board on cable CE26015 from Power Distribution Board.</p> <p>If solid on, then it is not communicating with the motherboard. Check A5CBL5900 USB cable. Swap cable with the light board.</p> <p>Watch while coining up and see if it flashes for a short time. Check A5CBL5900 USB cable. Swap cable with the light board</p> <p>Replace Wheel Board if needed. Part # AACB26000</p>
<p>Monitor not working</p> <p>Power down, wait 5 minutes and power up again.</p>	<p>Monitor shows "No Signal"</p>	<p>Monitor VGA cable unplugged from motherboard or back of monitor.</p> <p>Faulty or loose RAM on motherboard</p> <p>Large power connector unplugged on motherboard</p> <p>Small power connector unplugged on motherboard</p> <p>Faulty power supply - Refer to Power Supply diagnostic section</p> <p>Faulty motherboard - Replace faulty board. (AAMB12-HD/LTM)</p> 
<p>Monitor has nothing at all on power up.</p>	<p>Power cable unplugged from monitor</p> <p>Faulty monitor.</p>	<p>Ensure power is plugged into back of monitor, down to power strip.</p> <p>Replace monitor. (A5MO2221)</p>
<p>Error on screen at power up.</p> <p>Re-Boot game to see if problem still exists.</p>	<p>Display shows "Kernel panic – unable to mount root"</p> <p>Display shows upside down motherboard Bios</p> 	<p>Faulty or loose RAM, faulty software, faulty motherboard</p> <p>No hard drive in motherboard.</p> <p>Replace with AAHD0032-LTM</p> 
<p>Home Sensor not working properly</p>	<p>Inspect assembly for physical obstruction</p> <p>Disconnected, loose or broken wires.</p> <p>Test Sensor.</p> <p>Faulty sensor.</p>	<p>The metal tab on the left side of the wheel (from the back) must pass over sensor at a distance of 1/2" Too close is bad, too far away is bad. Ensure the metal tab is clean and reflective.</p> <p>Check connections from opto sensor to I/O board. Refer to wiring diagram. (Cable # CE26007)</p> <p>Enter Diagnostic Menu, Wheelboard area to see if game recognizes sensor. Screen will flash "Home Sensor" when sensor is seen. Once per revolution.</p> <p>Replace sensor if needed. AACB4403</p>

TROUBLESHOOTING GUIDE

Problem	Probable Cause	Remedy
Encoder Sensors not working properly	<p>Inspect assembly for physical obstruction</p> <p>Disconnected, loose or broken wires.</p> <p>Test Sensor.</p> <p>Faulty sensor.</p>	<p>There are 2 identical sensor boards in the arrow housing. 2 sets of optos watch the notches on the edge of the wheel. These sensors keep track of how many notches pass by to determine wheel position. The home sensor will reset this count.</p> <p>Check connections from opto sensors to I/O board. Refer to wiring diagram. (Cable # CE26019, CE26011) The cable with the white wire must attach to the front sensor.</p> <p>Enter Diagnostic Menu, Wheelboard Section to see if game recognizes sensor. Will flash “Notch Sensor” when sensor sees a notch. Screen will also show the ticket value on the screen as the wheel is turned downward.</p> <p>Replace arrow sensor if needed. Part # AAPO26000</p>
Pushing plunger does not spin wheel	<p>Inspect assembly for physical obstruction</p> <p>Solenoid is not engaging.</p>	<p>The solenoid assembly should pivot as handle is pushed down. The wheel will only turn if the solenoid is engaged. Refer to “Pivot Assembly Exploded View” to identify worn parts to replace.</p> <p>Refer to “Solenoid does not activate”</p>
Solenoid does not activate 	<p>Inspect assembly for physical obstruction</p> <p>Disconnected, loose or broken wires.</p> <p>Test solenoid.</p> <p>Faulty solenoid.</p> <p>Wheel Board communication: Red and yellow power LED's should be on.</p>	<p>Refer to “How to Remove Wheel” to access the solenoid assembly Ensure assembly is loose and moves freely.</p> <p>Check connections from solenoid to Wheel Board. Refer to wiring diagram. (Cable # CE26000)</p> <p>Enter Diagnostic Menu and select “Engage Wheel”. The solenoid should now receive 12 Volts DC.</p> <p>Replace solenoid assembly if needed. AASO26001</p> <p>If it is off, then check 12 & 5 Volts DC coming into board on cable CE26015 from Power Distribution Board.</p> <p>If solid on, then it is not communicating with the motherboard. Check A5CBL5900 USB cable. Swap cable with the light board.</p> <p>Replace Wheel Board if needed. Part # AACB26000</p>
Solenoid is on all the time	<p>Inspect assembly for physical obstruction</p> <p>Check for 12 Volts DC on solenoid cable CE26000</p>	<p>Refer to “How to Remove Wheel” to access the solenoid assembly Ensure assembly is loose and moves freely.</p> <p>If 12 Volts DC is always present, the Wheel Board AACB26000 is faulty and will need to be replaced.</p> <p>If no 12 Volts DC and solenoid is still engaged, the solenoid assembly AASO26001 is faulty and will need to be replaced.</p>
Wheel values are a bit off target	<p>Ensure the wheel is not rocking backward as it comes to a stop.</p> <p>Arrow sensor needs adjustment</p>	<p>The wheel brake should be tighten to ensure the wheel does not rock backward over a notch when it comes to a stop. Enter Diagnostic Menu, Wheel Debug, Select Engage Wheel and spin the wheel fast. Refer to “How to Adjust Brake Tension”</p> <p>Refer to “How to Adjust Arrow Sensor”</p>

TROUBLESHOOTING GUIDE

Problem	Probable Cause	Remedy
<p>Game not coining up</p> <p>If installing a card swipe reader, refer to Card Swipe System Installation page in front of manual.</p>	<p>Check for I/O board USB cable communication.</p> <p>Ensure game makes sound when coin switch is triggered.</p> <p>Game set to large amount of credits per game.</p>	<p>Refer to “I/O Aux Board Issue” diagnostic Section.</p> <p>Check coin switches—both should be wired normally open. If one switch is “closed” the other will not work either. Check wiring to I/O Board. (AACBL4A-DOORA, CE26013)</p> <p>Check 12 Volt power in from Power Dist Board.</p> <p>Check Game Setup Menu. Ensure Credits in Payout Settings menu is set. Default = 1</p>
<p>Menu Buttons do not work</p>	<p>Swap connectors at the 2 buttons.</p> <p>Pinched, broken, or disconnected wiring</p> <p>Main board faulty.</p>	<p>Replace button if problem stays with button.(AAPB2700)</p> <p>Inspect crimp to ensure good connection.</p> <p>Check connections from menu buttons to I/O board.</p> <p>Check continuity on wires. (AAPB2700, CE26012)</p> <p>Replace I/O Aux Board. (AACB9605A-CBL)</p>

BILL ACCEPTOR DIAGNOSTICS

Note: There are many different models and brands of Bill Acceptors that are used on redemption games. Your Bill Acceptor may differ from the unit shown. Standard DBA is MEI # AE2454-U5E Part # A5AC9101 Only use 12 Volt DC Bill Acceptor

Determine if Bill Acceptor has power:
Turn game ON—The bill acceptor should make noise as stacker cycles and green lights on outside bezel should flash.


If NO power:
Use meter to measure 12 VDC voltage at cable going into Bill Acceptor from front I/O Aux Board

If power is OK:
Clean Bill Acceptor path to make sure there is nothing jamming unit.
Check dipswitch settings on side of acceptor.
Make sure switch # 8 is OFF for Always Enable





ERROR CODES

Count the number of flashes on front bezel of Bill Acceptor and follow on Bill Acceptor chart for repair instructions.



POWER SUPPLY DIAGNOSTICS

- 1.) Verify AC power to game. Check power strip in front door. The rocker switch should be illuminated.
- 2.) Check connection to power supply.
- 3.) Ensure Power Supply switch is set to 115V (or 230V)
(Some model power supplies may not have this)
- 4.) Ensure Power switch is on.
- 5.) Ensure fan is turning.
 - If power supply fan is turning and there is no 12 Volt out:
Check power supply cables to the Power Distribution Board.
This board takes the power in, and directs it to the different 12 volt loads.



Unplug all power out connectors from the top of the Power Distribution Board. Turn on game and if it boots correctly, plug one cable in at a time until the issue is found.

Replace power supply if this board is not receiving 12 volts. (A5PS1021)

- If power supply fan is not turning, then continue to "Verify Power to Motherboard"

Verify Power to Motherboard

The motherboard will turn on the power supply.

If your game has no 12 volts, it may be the motherboard not turning on.

Also - there may be a 12 volt short somewhere in cabinet that is not allowing the power supply to turn on.

Minimize load on power supply and isolate short

Unplug the power supply cables going to the Power Distribution Board.

This will leave the power supply, motherboard, and monitor left plugged in together.

If power supply, motherboard, and monitor now turn on:

Plug in the Power Distribution Board to power supply, but unplug all of the outputs from the board.

Turn on game and verify the 12 volts is good.

Then plug in one component at a time to power supply to locate short.

If power supply still does not power on, then replace power supply (A5PS1021), or replace motherboard. (AAMB12-HD/LTM)

HOW TO CHANGE SOFTWARE

New Software Installation:

The hard drive contains all the information about the game: Credits per play, ticket pattern, etc. Be sure to check this information after finishing installing new software.

Turn off game by flipping the power switch on the power strip.

Locate hard drive on motherboard.

Remove this screw with a small #1 Phillips screwdriver.

There is a small white plastic spacer under the screw.


Leave this on the board, the M.2 drive will rest on top of this spacer.

Remove the old software.

Slide the M.2 new software drive into the slot on the motherboard as shown.

Notice the white spacer is still on the motherboard.

Using a small # 1 screwdriver, re-insert the screw into the motherboard to secure the software.



I/O AUX BOARD PINOUT



- = +12 VDC
- = Ground
- = +5 VDC
- = Output
- = Input

Outputs:

- Q1 (PD1) Game counter
- Q2 (PD0) Tickets counter
- Q3 (PD6) Coin Lockout
- PE6 Ticket Enable

Inputs:

- PD4 Menu Button
- PC6 Select Button
- PD7 Ticket Notch
- PB4 Coin In
- PB5 DBA In
- D15 (A1) Low Ticket Switch Input

HOW TO OPEN THE FRONT PLEXI


The front plexi can be removed from the game to allow monthly cleaning.

Instructions:

Remove the back door of the game and set aside.

Open the front door and locate the 2 latches securing the front plexi in place.

The front plexi will now slide up (like a roll top desk) and can be removed from the back of the game.



HOW TO REMOVE ARROW SENSOR

The arrow sensor must be removed to replace, or when removing the wheel to replace the solenoid.

Tools Needed:

Phillips Screwdriver # 2 Square bit

Instructions:

The front plexi must be open or removed to access the arrow sensor.

Refer to "How to Open the Front Plexi" to remove plexi.


Once plexi is removed, remove the 2 screws attaching blocking plate to the white plastic using a # 2 square bit screwdriver.

Loosen, but do not remove, the 1 bolt using a Phillips screwdriver.

Remove the "Win" arrow metal plate by sliding to the left.

Remove the 2 Phillips screws from the top rail.

The arrow sensor assembly can now be unplugged and removed from the cabinet.



AAPO26000
Arrow Sensor Assy

HOW TO ADJUST ARROW SENSOR

The wheel sensor “sees” the notches on the right side of the wheel. As the game is played, the wheel spins downward and the ticket value changes as the point of the arrow crosses the dividing line. If the wheel value changes too early or too late, the sensor must be adjusted.

Tools Needed:

Phillips Screwdriver


Instructions:

The front plexi must be open, refer to “How to Open the Front Plexi”.

Use a Phillips screwdriver to turn the screw on the bottom of the arrow assembly.

Clockwise will raise the sensor.

Counter-clockwise will lower the sensor.



HOW TO ADJUST BRAKE TENSION

The wheel brake is spring tensioned pad that pushes against the wheel to slow and stop the wheel after a “good spin speed” has been reached.

Too tight of brake tension will stop the wheel quickly and may allow a skilled player to master the technique and achieve more bonus wins.

Too loose of brake tension may allow the wheel to rock backwards as it comes to a stop. If it rocks backward over a notch, the tickets won will be incorrect.

Instructions:

Remove the back door of the game and set aside.

Use a needle nose pliers to loosen the nuts on the threaded eye hook.


Adjust threaded eye hook up - to increase tension on wheel brake.

Adjust threaded eye hook down - to decrease tension on wheel brake.

To test brake tension: Enter Diagnostic Menu, Wheel Debug Menu.

Enable Engage Wheel and push the handle to spin the wheel fast.

The screen will show “tighten Brake”, “Loosen Brake”, or “Brake OK”



HOW TO REMOVE HOME SENSOR

The home sensor is located on the left side of the wheel, when looking from the back of the game.

Tools needed: 7/16" Wrench

Instructions:

Unlock the back door using a H95 key.

Remove the back door by using both handles to lift upwards and pull out.

To allow more room to remove sensor, first remove the top nut of wood side brace using a 7/16" wrench, and remove the bolt.

Swing the wood side brace down and out of the way.





The wood block is designed to slide off this top post once the bottom bolt is removed:

Remove the bolt, lock washer, and washer from the lower end of the wood block using a 7/16" wrench.

The wood block with the sensor attached will now slide off the top post.

The sensor can now be cleaned or replaced if needed by removing the 2 Phillips screws. Sensor is part # AACB4403



HOW TO REPLACE MONITOR

The 22" monitor can be removed from the back top of the game

Tools Needed:

1 step ladder (4-6 foot) # 2 Square bit
Phillips Screwdriver

Instructions:

Carefully climb to the top rear of cabinet.

Remove the 4 bolts using a Phillips screwdriver.


Remove the 4 screws using a # 2 square bit.

Disconnect VGA from the top of the monitor.

Unplug power cord from the top of the monitor.

The monitor can now be removed and replaced. Monitor part # A5MO2221

Note: The monitor is purposely installed in the cabinet upside down for optimal visibility.



HOW TO REPLACE SOLENOID

The wheel must be swung outward to access and replace the solenoid assembly.

Tools Needed:

Phillips Screwdriver # 2 Square bit 7/16" wrench 1/2" wrench

Instructions:

The arrow sensor must be removed so it does not **damage** the wheel, refer to "How to Remove Arrow Sensor"

Remove the 2 top nuts, lock washers, and washers of wood side braces using a 7/16" wrench, and remove the bolts.



Swing the 2 wood side braces down.

The wheel will tilt down and rest on these braces.



Remove the top cable clamp using a # 2 square bit screwdriver.



Remove the bottom cable clamp using a # 2 square bit screwdriver.

Remove the cotter pin (part # A5PICZ001) and slide the wheel link off of the pivot arm.

Unplug the 2 pin molex connect for solenoid power.

Remove the 2 top nuts, lock washers, and washers of wheel cradle frame using a 1/2" wrench, and remove the bolts.



HOW TO REPLACE SOLENOID

Slowly pivot the wheel cradle downward to rest on wood side braces.

Before we disassemble the center wheel hub to remove the solenoid assembly, the wheel itself needs to be supported. This will prevent the wheel from twisting and causing **damage**.

There are 2 wood blocks that are shipped with the game in the coin box, with a bolt, lock washer, and washer.



A5BOHH060



A5WASI020



A5WAFL060





Slide the long narrow piece into the slot of the other piece to create a shelf.



Install the bolt, lock washer, and washer using a 7/16" wrench as shown.


Ensure the wheel is supported before continuing.

Note: When re-installing the wheel link to the pivot arm, bring the arm up toward the rear of the game and attach. This will make sure the solenoid is swung to the correct position.




HOW TO REPLACE SOLENOID

After wheel is supported, remove the retaining ring and side metal arm from solenoid assembly.




Remove the 6 screws using a Phillips screwdriver.

Remove the center bolt and star washer using a 7/32" Allen wrench.




Remove the metal plate, and remove the white plastic spacer from the wheel shaft.



The solenoid assembly (AASO4010) can now be removed from the wheel shaft.


Upon installation of the new solenoid assembly, make sure the cable is routed through the metal retaining clip. This will keep the cable away from the wheel as the handle moves up and down.



PIVOT ASSEMBLY EXPLODED VIEW



Lil Ticket Monster Pivot Assembly Exploded View Diagram



DECAL DIAGRAM



PARTS NOT VISIBLE

- A5DE22503 Left Bottom Side Cabinet Decal
- A5DE22505 Left Cabinet Rail Decal
- A5DE22508 Left Wheel Side Decal
- A5DE22522 Left Marquee Arm Decal

PARTS LIST

PART #	DESCRIPTION	PART #	DESCRIPTION
A5BK9999	Bracket, Power Supply Mounting	A5DE22511	Decal, Plunger Wrap
A5BRMP010	2 1/2" X 3/4"W Flat Mending Plate	A5DE22512	Printed Plexi, Plunger Base
A5BRMP020	5 1/8" X 3/4"W	A5DE22513	Printed Plexi, Console
A5BURU075	Bumper, Black Rubber, 2 1/4x2 5/8	A5DE22514	Decal, Cabinet Bottom Front
A5CB8020	Cash Box	A5DE22515	Decal, Cabinet Front Door
A5CL1004	Clamp, Versa Latch, 2 Per Game	A5DE22516	Plexi Rolux Ticket Piece
A5CO4400	Grip Cover for Handle, 2 Per Game	A5DE22522	Decal, Marquee Arm, Left
A5GU4400	Guard, Bent Wire	A5DE22523	Decal, Marquee Arm, Right
A5LK2001	Lock, Cash Box, A05/E00 Key Code	WACA26056	Side Window, Acrylic, 2 Per Game
A5LK5002	Lock, 7/8", H95 Key Code, 2 Per Game	WACA26030	Front Window (Plexi Only)
A5PL0010	Plug, Fits 1" Tube OD, 2 Per Game	WAWM0036	Handle Guide, Black Plastic
A5RO8800	Rod, 18.092 Inch, 8 Per Game	W5TM2300	Orange T Molding (14.5 Feet Per Game)
A5SLSX001	Shaft Collar, 3/4"Bore, 2 Per Game	W5TM4006	Yellow T Molding (14.5 Feet (173") Per Game)
A5SP5021	Spring, Compression	AAVF22500	Vacform Eyeball with Decal
A5SREX050	Spring, 6", 3/8"Od, .041" Wire	A5ME2034	Ticket Tray
AASW200	Switch, Score/Low Ticket Switch	A5ME26000	Metal, Arrow Wire Cover
AAWH26000	Bottom Roller Wheels, 2 Per Game	A5ME26001	Metal, Caster Plate, 2 Per Game
AABK1013	Bracket, Pushbutton/Counters	A5ME26005	Metal, Pointer Front
AACO1020	Ticket & Game Counter Assy	A5ME26006	Metal, Side Guards, 2 Per Game
AAHA26000	Handle Assembly With Grips	A5ME26007	Metal, Side Window Rail, 2 Per Game
AAPO26000	Sensor Assembly For Pointer	A5ME26008	Metal, Sliding Window Rail
AASO26001	Solenoid Assembly With Bracket	A5ME26009	Metal, Sliding Window Handle
AATURU001	Orange Rubber Tubing, 2 Per Game	A5ME26010	Metal, Wheel Mounting Plate
W5HG1025	Hinge, 16", Double Bend	A5ME26011	Metal, Wheel Shaft
W5HG1065	Hinge, 5-75, Single Bend	A5ME26012	Metal, Wheel Support Bracket
W5KE5000	Keeper, Lock, 2 Per Game	A5ME26013	Metal, Window Brace, 2 Per Game
A5DE0042	Decal, Menu/Volume Decal	A5ME4167	Metal, Solenoid Link
A5DE0044	Decal, Remove Arrow Before Wheel	A5ME4182	Metal, Cashbox Guide
A5DE22500	Printed Plexi, Ticket Marquee	A5ME4414- BLK	Metal, Handle Guide Assy
A5DE22501	Decal, Top Monster Wrap	A5ME4417	Metal, Pivot Link, 2 Per Game
A5DE22502	Decal, Eyeball	A5ME4418-BLK	Metal, Wheel Link
A5DE22503	Decal, Cabinet Side Bottom, Left	A5ME4420	Metal, Pivot Link Bracket, 2 Per Game
A5DE22504	Decal, Cabinet Side Bottom, Right	A5ME4429	Metal, Bracket, Solenoid
A5DE22505	Decal, Cabinet Rail, Left	A5ME4430	Metal, Slip Clutch Bracket
A5DE22506	Decal, Cabinet Rail, Right	A5ME8812	Metal, Handle Rod, 2 Per Game
A5DE22507-1	Decal, Wheel Wrap, Pattern # 1	A5ME8816	Metal, Rocker Arm
A5DE22507-2	Decal, Wheel Wrap, Pattern # 2	A5PL4200	Mounting Plate For 12 Volt DC Bill Acceptor
A5DE22507-3	Decal, Wheel Wrap, Default Pattern #3	A5PL8900	DBA Blanking Plate For 12 VDC Bill Acceptor
A5DE22507-4	Decal, Wheel Wrap, Pattern # 4	A5PL9995	Blanking Plate for Coin Door
AADE22510	Ticket Cover Up Wheel Decal Set	A5PL9998	Blanking Plate for Ticket Dispenser
A5DE22508	Decal, Wheel Side, Left	A5CBL5900	Cable, USB, Male A -Male Micro, 3 Per Game
A5DE22509	Decal, Wheel Side, Right	A5CE2300	Cable, Audio Isolator
A5DE22510	Decal, Pointer Arrow	A5CORD1	Cord, Power, 10'


PARTS LIST

PART #	DESCRIPTION	PART #	DESCRIPTION
A5CORD20	Cable, 10', SVGA	AACE26019	Arrow Sensors
A5CORD21	Cord, 3', 3.5mm Male to Male, Audio Cable	AACE26020	Ground Stud to Plunger
A5CORD5	Cord, AC Computer Cord, 6.5'	AACE26021	Ground Stud to Door Hinge
A5CORD5000	Cord, Power Strip Adapter, 1ft. 2 Per Game	AACE26023	Ground Stud to Ticket Dispenser
AACE1710	Cable, 4" Door Ground Cable, 2 Per Game	AACE26029	Wheel Lights, 2 Per Game
AACE1715	Cable, Door Ground Cable	AACE26030	Window Outer Frame Light, 2 Per Game
AACE22500	Line Filter Cord to Power Strip	AACE26032	Plunger Accent Light
AACE22501	Console Addressable Power	AACE26033	Outside Console Light
AACE22502	Middle Marquee Light Power Jumper	AACE8811A	Cable Assy, Speaker
AACE22503	Outside Marquee/Eyeball Power Jumper	AAPB2700	Push Button, 2 Per Game
AACE22504	Middle Marquee Light Power	AACBL4A-DOORA	Door Cable
AACE22505	Outside Marquee/Eye Power	A5FI9010	Filter, Inline
AACE22506	Eyeball Light Board	A5AC9101	Bill Acceptor, 12 Volt DC
AACE26000	Solenoid Power from CB26000	A5MO2221	Monitor, 22"
AACE26001	Speaker Wire from CB9600	A5OU5000	Outlet Strip
AACE26004	White Console Lights Power	A5PS1021	Power Supply, 450 Watt
AACE26007	Power to Home Sensor from CB26000	A5TD1	Ticket Dispenser
AACE26008	DBA Cable from CB9605 Board	AACB15001	PCB Assy, Bleed Resistor Board
AACE26010	Console RGB Light Power from CB8001	AACB26000	PCB, Wheel Control, Minions
AACE26011	CB26000 Encoder Sensor to Arrow	AACB4403	Reflector Sensor
AACE26012	CB9605 Board to Menu/Counters Bracket	AACB5156	Power Distribution Board
AACE26013	CB9605 Board to Coin Door and Tickets	AACB8001-LTM	Light Driver Board
AACE26014	Power Distribution Board to CB9605	AACB9600A	Audio Amplifier Board
AACE26015	Power Distribution Board to CB26000	AACB9605-CBL	Door Interface Board
AACE26017	Power Distribution to CB8001 Power	AAHD0032-LTM	M2 SATA, Lil Ticket Monster
AACE26018	Power Distribution to CB9600 Power	AAMB12-HD/LTM	Motherboard, Lil Ticket Monster W/Sata

PARTS PICTURES



A5BK999 A5BRMP010 A5BRMP020 A5BURU075 A5CB8020 A5CL1004 A5CO4400 A5GU4400



A5LK2001 A5LK5002 A5PL0010 A5RO8800 A5SLSX001 A5SP5021 A5SREX050 A5SW220



AAWH26000 AABK1013 AACO1020 AAHA26000 AAPO26000 AASO26001 AATURU001 W5HG1025



W5HG1065 W5KE5000 A5DE0042 A5DE0044 A5DE22500 A5DE22501 A5DE22502



A5DE22503 A5DE22504 A5DE22505 A5DE22506 AADE22510 A5DE22507-1 A5DE22507-2




A5DE22507-3 A5DE22507-4 A5DE22508 A5DE22509 A5DE22510 A5DE22511 A5DE22512



A5DE22513 A5DE22514 A5DE22515 A5DE22516 A5DE22522 A5DE22523

PARTS PICTURES



WACA26056



WACA26030



WAWM0036



W5TM2300



W5TM4006



AAVF22500



A5ME2034



A5ME26000



A5ME26001



A5ME26005



A5ME26006



A5ME26007



A5ME26008



A5ME26009



A5ME26010



A5ME26011




A5ME26012



A5ME26013




A5ME4167



A5ME4182



A5ME4414-BLK



AAME4417



A5ME4418-BLK



A5ME4420



A5ME4429



A5ME4430



A5ME8812



A5ME8816



A5PL4200



A5PICZ001



A5PICZ010



A5PL8900



A5PL9998



A5CBL5900



A5CE2300



A5CORD1



A5CORD20



A5CORD21



A5CORD5



A5CORD5000



AAACE1710



AAACE1715



AAACE22500



AAACE22501



AAACE22502



AAACE22503



AAACE22504



AAACE22505



AAACE22506



AAACE26000



AAACE26001

PARTS PICTURES



AACE26004



AACE26007



AACE26008



AACE26010



AACE26011



AACE26012



AACE26013



AACE26014



AACE26015



AACE26017



AACE26018



AACE26019



AACE26020



AACE26021



AACE26023



AACE26029



AACE26030



AACE26032



AACE26033



AACE8811



AAPB2700



AACBL4A-DOORA



A5FI9010



A5AC9101



A5MO2221



A5OU5000



A5PS1021




A5TD1



AACB15001




AACB26000




AACB4403



AACB5156



AACB8001-LTM



AACB9600A



AACB9605-CBL



AAHD0032-LTM



AAMB12-HD/LTM

TECHNICAL SUPPORT

Excellent customer service is very important to Bay Tek Entertainment! We know that keeping your games in great operating condition is important to your business. When you need us, we are here to help. You can call us for free technical assistance, and you can count on us to have parts on-hand to support your game. When you do need us, it's important that you know what to expect.

We offer options that fit your needs.

Electronics / Circuit Boards:

· **Repair & Return** – If you have Circuit Board issues with your Bay Tek product you can send the board to us and we'll repair it right away. Most items sent to us are repaired and returned to you within two days. This option is your best value as we offer this fast turn-around service at the most reasonable price.

· **Advance Replacement** – If you have Circuit Board issues with your Bay Tek product, but you don't have time to send your board in for repair, give us a call and ask for an Advance Replacement. We'll send you a replacement board that same day (pending availability). When you get your new board, just repackage the defective board in the same box and send it back to us. We make it easy by including a UPS Return-Shipping label for you to put on the box.

This is your best option when you need to get your game up and running as quickly as possible!

· **Spare Parts** – Take matters into your own hands and purchase new spare Circuit Boards for your Bay Tek games. Many of our games share the same main-board electronics. This means you can buy one set of spare electronics to support many of your Bay Tek games. Spare boards allow you to get your game up and running the quickest and provide you a valuable troubleshooting option. Call our technicians to get recommendations for what you should keep on hand for spare parts!

Technical Support:

“You” are the best tool for troubleshooting! Your abilities to understand the game and your skills to repair the game are invaluable to us! If you need help, you know you can call us. It's not easy to diagnose a game remotely by phone, but our technicians do a great job. They'll need your help to perform some troubleshooting steps and convey to them exactly what's happening with your game.

Returns & Credits:

Sometimes the issue isn't what it seemed to be. If you chose the Advance Replacement option and now need to return that circuit board, just give us a call to get Return Authorization. You will be credited for the cost of the board and charged only the bench fee for our processing and retesting that board. If you choose the Repair and Return option, we'll test your board before we begin. If no problems are found, you will only be charged the bench fee.

Note: Bench fees apply regardless of whether the repair was your choice or a recommendation from a Bay Tek Entertainment technician.

It's a small price to pay for troubleshooting the issues with your game.

[You can count on our Technical Support Team for service and support!](#)



WARRANTY OPTIONS

Bay Tek Entertainment warrants to the original purchaser that the game will be free of defects in workmanship and materials for a period of 12 months from the date of shipping.

Bay Tek Entertainment will, without charge, repair or replace at its option defective product or component parts upon notification to the parts/service department.

New, purchased parts have a 30 day warranty.

Any labor expended is not included in this warranty.

Warranty replacement part(s) will be shipped immediately via ground service, along with a Return Material Authorization (RMA) number for the return of defective part(s). Defective part(s) must be shipped back to Bay Tek Entertainment unless otherwise instructed.

This warranty does not apply in the event of any misuse or abuse to the product, or as a result of any unauthorized repairs or alterations. The warranty does not apply if the serial number decal is altered, defaced, or removed from its original position.

Should you need your game serviced, determine the serial number from the decal on the back of the game cabinet or main board, and call **920.822.3951 Ext. 1102**
or e-mail to: baytek.service@thevillage.bz

REPAIR OF NON-WARRANTY PARTS

Should your game need servicing, determine the serial number from the decal on the back of the game cabinet, inside front door, or the cover of this manual and call **920.822.3951 Ext. 1102**

or e-mail to: baytek.service@thevillage.bz

An estimate of the repair charges will be quoted to you for approval.

You may now proceed in one of two ways.

Option 1:

Request immediate shipment of advance replacement part(s).

You will receive the part(s) with

an **RMA** for the return of the faulty part(s).

You must return the faulty part(s) in 14 days to avoid additional charges.

Option 2:

Call the Service Dept at (920) 822-3951 Ext. 1102 to receive a RMA to send the faulty part(s) in for repair

Please include the following information

NAME

ADDRESS

PHONE #

SERIAL #

PURCHASE ORDER NUMBER or

AUTHORIZATION to perform service.

Repaired part(s) will be shipped back using the same method in which they were received.

Repairs are warranted for 30 days from the date of installation.